


Product Instructions



Retractable Craft Knife

CHANGING THE BLADES



Remove end cap from retractable craft knife, and pull blade from knife body. Dispose safely, replace with sharp blade and reassemble.